

USB VoIP Phone

User Manual



1. Instruction

1.1 Summary

Plugging USB VoIP Phone into your computer's USB port, you can make and receive skype calls. Phone rings for all incoming calls. With keypad and ringer, it is easily used as mobile phone.

1.2 Features

1. Keypad and ringer, easy to use like mobile phone
2. Phone rings for all incoming calls, ring style selectable
3. Dial skype contact and Skypeout number by phone keypads
4. Echo cancellation, noise reduction, duplex communication
5. Driver and sound card built-in, no external power required

1.3 System Requirements

1. Windows 2000 or XP
2. 400MHz processor and free USB1.1 or USB2.0 port
3. 128MB RAM and 15MB free disk space
4. Any broadband connection or minimum 33.6 Kbps dialup

1.4 Package Contents

1. One USB VoIP phone
2. One user manual
3. One installation CD
4. One extra face slip

2 Using the USB VoIP Phone

2.1 Keypad Instruction



Use this button to switch between the tabs of the Skype software

▲/▼: Up/Down

Use these buttons to scroll through the list of contacts and calls in the Skype software.



: Dial/Answer

Place or answer a call.



: Hang up

End a call or refuse an incoming call.

C: Delete Key

Press this button to clear any numbers you have entered for a call

RING Key

Press this button repeatedly to cycle through the various ringtones.

MUTE Key


Press to mute the microphone

2.2 Run Skype

- Download Skype software and install it (www.skype.com).
The version must be 1.0.0.106 or higher.

- Run Skype and log in with skype account.


You can create a Skype account as shown below:



After software startup, the icon will appear to the system tray as shown below:



That indicates the Skype are successfully connected to Internet.


If the icon is shown as , you have to check your Internet connection.


2.3 Connect USB VoIP Phone to PC

- Connect the USB plug of the USB Phone to an available USB port on your computer.

2.4 Run SkypeMate

- Insert SkypeMate installation CD or download SkypeMate software, then install it.
- **Run SkypeMate**

Double-click the icon  on the desktop, the Skype program will pop up the window as shown below:




Select the first option “Allow this program to use Skype”, click “OK” button.


Note: If you selected the wrong option, you can make another selection. Please see **2.8. FAQ /problem4** for detail.

After running SkypeMate, the icon will appear to the system tray as shown:






That indicates the device and Skype are connected successfully.

If the icon shown as  (the phone is green and the outside is grey), please run Skype first.


If the icon shown as  (the phone is red and the outside is green), it means USB VoIP Phone connected incorrectly. Please reconnect USB VoIP Phone to PC.

2.5. Call Skype User from contacts and call list


- Press  to switch “Contacts” and “Call list” tabs on Skype software.
- Press  to select a contact.
- Press  to call out.

2.6 Call another Skype user


- Add "bbc456" to Contacts
- Assign Speed-Dial for it, example "11"




- Input number and call out:

Press digital "11" on USB VoIP Phone, this number will be shown on Skype window, then press  to call out.

2.7 Call to regular phone

- Press "00"+"country number"+"phone number", then press .

Example: call someone in Beijing, China, please press

00861012345678, and then press .

0086

10

12345678

country code

city code

destination number

Note: If you want to use this function, you should buy


SkypeOut Credit from www.skype.com first.




2.8 Answer a call

When a call comes in, the USB VoIP Phone will ring. Press  to answer the call, or press  to refuse the call.

2.9 Change the face slip

To change the face slip, please follow the pictures:






3 FAQ

Problem 1

I am not able to hear any sound through the earphone?

Solution

Please execute the “Control Panel->Sound and Video (🔊)
->Audio”, set **Sound Playback** and **Sound Recording**’s
preference device to your sound card. See below:




Problem 2

I can't play music through the USB Phone?

Solution

Please execute the “Control Panel->Sound and Video (🔊)
->Audio”, set **Sound Playback** and **Sound Recording**'s
preference device to “USB Audio Device”.




Problem 3

The voice is played from the PC's sound card instead of the
USB VoIP Phone when I make/answer a call?

Solution

Execute “Tools->Options->Sound Devices” to open the
window as below:



Set “Audio In” and “Audio Out” to “USB Audio Device”.

Problem 4

Skype is running, but the icon of SkypeMate still show as



(the phone is green and the outside is grey)?

Solution

You have selected the wrong option, go to Skype, execute choose “Tools-> Options-> Privacy-> “Manage other programs’ access to Skype”, choose the needed option, click “Change” button to open the “Manage API Access Control” windows, and make another selection.